


# Vista Plus End Cap

## SPECIFICATION & INSTALLATION


### WHAT TO KNOW

Our Vista Plus moisture resistant End Cap is used to transition from laminate to carpet, masonry (fireplaces), sliding doors, and other exterior door jambs.

#### Technical Dimensions:



#### Installation Illustration Example:



**Basic Dimensions:** 1 3/8" (w) x 1/2" (h)


**Surface Material:** High Wear Resistant Aluminum Oxide Laminate

**Core Material:** Exterior Grade Composite Wood Product


### INSTALLATION INSTRUCTIONS

**Pre-Installation Note:** Use the Versatrack and Versatrack Shim when installing.


**Step One:** Install the flooring planks, including the underlayment, by leaving a 1-1/8" inch (28mm) gap for the installation of the end cap molding.



**Step Two:** Center the U-Track and shim between the carpet and the laminate floor and screw them to the sub-floor by using #6 screws.



**Step Three:** Gently press the molding into the track starting from one end to the other just like you would close a Zip-Lock bag. **Note:** Do not try to push the entire molding in all at once by just pressing it in from the top!




# Vista Plus SlimTrim

## SPECIFICATION & INSTALLATION

### WHAT TO KNOW

Our Vista Plus moisture resistant SlimTrim functions as a reducer or t-mold. The molding comes with dowels for floors up to 3/4" (19mm).


#### Technical Dimensions:



#### Installation Illustration Example:


##### Reducer

(up to 3/4" and must be glued to non-floating surface)




##### Transition

(up to 3/4")



##### Dowel

(Requires a 1/4" hole")



**Basic Dimensions:** 2" (w) x .5625" (h)

**SlimTrim Surface Material:** High Wear Resistant Aluminum Oxide Laminate

**SlimTrim Core Material:** PVC


**Dowel Material:** Polystyrene

# Vista Plus Quarter Round SPECIFICATION & INSTALLATION

## WHAT TO KNOW

Our Vista Plus moisture resistant Quarter Round is used to conceal the required expansion space between the wall and the laminate flooring.

### Technical Dimensions:




**Basic Dimensions:** 3/4" (w) x 3/4" (h)

**Surface Material:** Decorative Paper

**Core Material:** Exterior Grade Composite Wood Product

### Installation Illustration Example:




## INSTALLATION INSTRUCTIONS


### INSTALLATION IF USING A WALL BASE

#### Step One:

Leave a gap between the wall and the floor as suggested by the Vista Plus installation instructions, but no more than 1/2" to allow the molding to sit on the floor.




**Step Two:** Apply two beads of adhesive on the back side of the molding as shown in the picture and then gently press against the wall and support it with something heavy until it has cured so that it will not pop off the wall.




#### Step Three:

Apply one thin bead of adhesive to the back of the quarter round or base shoe and attach it to the wall base molding and support it with a heavy object until the adhesive has cured so it won't pop off the wall base molding.



**Step Four (Optional):** Use finish nails in the Wall Base Molding every 16" and also through the Quarter Round or Base Shoe and into the Wall Base Molding. Finish up the nails with a color matching Color Fill!




# Vista Plus Quarter Round SPECIFICATION & INSTALLATION

## INSTALLATION INSTRUCTIONS

### INSTALLATION WITHOUT A WALL BASE


#### Step One:

Leave a gap between the wall and the floor as suggested by the manufacturer of the floor, but no more than 1/2" to allow the molding to sit on the floor!




#### Step Two:

Apply one thin bead of adhesive to the back of the Quarter Round or Base Shoe and attach it to the wall. Support it with a heavy object until the adhesive has cured so it won't pop off the wall (about 24 hours).



#### Step Three

**(Optional):** Use finishing nails in the Quarter Round or molding every 16".




# Vista Plus VersaEdge (Extra Tall)

## SPECIFICATION & INSTALLATION


### WHAT TO KNOW

Our Vista Plus VersaEdge stair nose molding combines style and function to enhance the beauty of a staircase or step. For use on flooring with an overall thickness of up to .75" (19mm).

#### Technical Dimensions:



#### Installation Illustration Example:



**Basic Dimensions:** 2" (w) x 1.5" (h)

**Surface Material:** High Wear Resistant Aluminum Oxide Laminate

**Core Material:** Aluminum


### INSTALLATION INSTRUCTIONS

#### FLOATING INSTALLATION METHOD

##### Step One:

Install the riser flush to the stair. Glue down flooring planks (for more details see manufacturers recommendations).

Then, clean flooring and molding as irected.




#### CLEANING PREPARATION FOR BOTH SURFACES

Preparing the floor & molding as outlined is mandatory to achieve the required bonding strength

1. Use a damp cloth (water only) to clean both surfaces of loose particles or surface films.
2. Roughen the surfaces with sandpaper (100-150 grit), sanding sponge or metal brush. For flooring, only roughen up area that will be covered (1.25" to 1.5").
3. Degrease both surfaces to remove all traces of oil, grease, dust, and fingerprints by using a solvent such as methyl ethyl ketone (MEK), acetone or isopropyl alcohol.
4. Let both surfaces dry thoroughly before applying PUR adhesive.


##### Step Two:

Turn VersaEdge over and roughen the inside surface of the VersaEdge to increase bond by means of 60 grit sandpaper, sanding sponge, or a metal brush.




### Step Three:

Next, apply a generous bead of a Premium Polyurethane Construction Adhesive along the entire inside corner.




### Step Four:

Touch the bottom of molding to the stair riser and carefully roll the stair nose in place. Make any final adjustments before you push the molding all the way down. Once it's in the final position, press down firmly with your hands and make your way down the entire stair nose. It may take 2 or 3 passes to set it firmly in place.



### Step Five:


Let the PUR adhesive cure for at least 4 hours before any walking on it. For exposure to full traffic, wait 24 to 48 hours. **NOTE:** Complete cure takes 48 hours.



## “LOCK-DOWN” INSTALLATION METHOD

### Step One:

Install the riser flush to the stair. Cut a 1” wide strip of your floor. Drill, counter-sink, screw and glue it flush to the stair riser. Install flooring 0.375” from the glued down 1” strip. Do not glue flooring down. Clean flooring and molding as directed.




## CLEANING PREPARATION FOR BOTH SURFACES

Preparing the floor & molding as outlined is mandatory to achieve the required bonding strength

1. Use a damp cloth (water only) to clean both surfaces of loose particles or surface films.
2. Roughen the surfaces with sandpaper (100-150 grit), sanding sponge or metal brush. For flooring, only roughen up area that will be covered (1.25” to 1.5”).
3. Degrease both surfaces to remove all traces of oil, grease, dust, and fingerprints by using a solvent such as methyl ethyl ketone (MEK), acetone or isopropyl alcohol.
4. Let both surfaces dry thoroughly before applying PUR adhesive.

### Step Two:

Turn VersaEdge after following the cleaning preparation above.




# Vista Plus VersaEdge (Extra Tall)

## SPECIFICATION & INSTALLATION


### Step Three:

Next, apply a generous bead of a Premium Polyurethane Construction Adhesive along the entire inside corner. Be sure to NOT put adhesive towards the front of the molding. Be sure to NOT put adhesive towards the front of the molding.



### Step Four:

Touch the bottom of molding to the stair riser and carefully roll the stair nose in place. Make any final adjustments before you push the molding all the way down. Once it's in the final position, press down firmly with your hands and make your way down the entire stair nose. It may take 2 or 3 passes to set it firmly in place.



### Step Five:

Let the PUR adhesive cure for at least 4 hours before any walking on it. For exposure to full traffic, wait 24 to 48 hours. **NOTE:** Complete cure takes 48 hours.

